

1 YEAR LIMITED WARRANTY

Your Wolfgang Puck Petite Kettle is warranted to be free of defects under normal household use to the original purchaser for 1 year.

This warranty excludes damage caused by negligence, overheating, misuse or abuse, and does not apply to scratches, stains, discoloration or other damage which does not impair the functionality of the product.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Proof of purchase is required to validate the warranty.

Shipping and handling charges may apply.

For questions or concerns please contact customer service at:

Synergy Housewares, LLC.

Toll-free: 866-444-4033

Hours: M-F 9:00am-5:00pm EST

Website: warranty.synergyhousewares.com

Printed in China

Model SWPSSPK1

WOLFGANG
PUCK /
USE AND CARE

PETITE KETTLE



Actual product may differ slightly from images in this manual
Wolfgang Puck is a trademark of Wolfgang Puck Worldwide

Model SWPSSPK1



Wolfgang Puck

Petite Kettle Use and Care

IMPORTANT SAFEGUARDS

Please read all the instructions carefully before using your Wolfgang Puck Petite Kettle to ensure safe operation and prevent injury.

Scalding Hazard Warning

- **Use the Infuser Lid only when the Infuser Basket is inserted.**

⚠ Never heat water with the **Infuser Basket** in the Kettle. Failure to do so may result in hot water or steam escaping unexpectedly.

- **Use the Kettle Lid only when the Infuser Basket is not installed.** When using the Kettle without the **Infuser Basket**, press the **Kettle Lid** firmly into the Kettle Opening until it is fully seated.

⚠ Using the wrong lid combination may result in scalding.

- **All Parts Get Hot During Use**

This stainless steel Kettle conducts heat and will become hot during use.

⚠ Always use oven mitts or potholders when touching any part of the Kettle during or after heating.

- **Use Caution Around Steam and Spout**

Steam released from the spout is extremely hot. **Always** point the spout away from yourself and others.

⚠ **Always** use protective oven mitts or potholders when handling the Kettle.

- **Do Not Overfill**

Never fill the Kettle with more than **14 ounces of water**.

⚠ Overfilling may cause hot water to spill during boiling.

Before Your First Use

Wash all parts in warm water with mild dish soap using a soft sponge or nylon pad. Rinse thoroughly and dry completely.

Using the Kettle Without the Infuser Basket

- 1 Add up to 14 ounces of water to your Kettle (see Figure 1) and ensure your **Kettle Handle is upright** during use.

⚠ Overfilling may cause hot water to spill during boiling.

- 2 Use the **Kettle Lid** only when the **Infuser Basket** is not installed.

- 3 Press the **Kettle Lid** firmly into the Kettle Opening until it is fully seated (see Figure 1).

- 4 Choose a **burner smaller than the Kettle Base** to prevent overheating the sides.

- 5 Use **medium to medium-high heat**. The encapsulated aluminum base heats quickly and evenly, so high heat is not necessary.

- 6 On gas stoves, prevent flames from rising along the sides, as this can damage or discolor the Kettle.

- 7 **Never leave the Kettle unattended** while heating.

- 8 After heating, turn off the heat and allow the Kettle to rest for **60 seconds** before lifting or pouring.

- 9 Always use an oven mitt or potholders when removing the Kettle from the stove and when pouring.




Figure 1

Using the Kettle with the Infuser Basket

⚠️ Never heat water with the Infuser Basket in the Kettle.

1 Fill your **Infuser Basket** with your choice of tea, loose-leaf or bagged. The typical ratio is 1 to 1 1/2 teaspoons (3 grams) of tea per 8 ounces of water; however, you can adjust it according to your personal taste. The large **Infuser Basket** allows the tea leaves to fully expand, extracting the best flavor from your tea. Place your **Infuser Lid** on your **Infuser Basket** and set aside. Do not put the **Infuser Basket** with **Infuser Lid** attached into the Kettle until step 10.

2 Add up to 14 ounces of water to your Kettle (see Figure 1) and ensure your **Kettle Handle is upright** during use.

⚠️ Overfilling may cause hot water to spill during boiling.

3 Press the **Kettle Lid** firmly into the Kettle Opening until it is fully seated (see Figure 1).

4 Choose a **burner smaller than the Kettle Base** to prevent overheating the sides.

5 Use **medium to medium-high heat**. The encapsulated aluminum base heats quickly and evenly, so high heat is not necessary.

6 On gas stoves, prevent flames from rising along the sides, as this can damage or discolor the Kettle.

7 **Never leave the Kettle unattended** while heating.

8 After heating, turn off the heat and allow the Kettle to rest for **60 seconds** before lifting or pouring.

9 Using an oven mitt or potholders, remove the Kettle from the stove, then carefully remove the **Kettle Lid**.

10 Insert the prepared **Infuser Basket** with **Infuser Lid** attached into your Kettle (see Figure 2) and press down firmly to retain the heat. Once the **Infuser Basket and Infuser Lid** are inserted, DO NOT return the Kettle to any heat source.

11 Allow the tea to steep to your desired strength before pouring. Flavor intensity depends on steeping time. Before pouring, ensure the **Infuser Lid** is securely attached to the **Infuser Basket**. Always use an oven mitt or potholders when removing the Kettle from the stove and when pouring.

Care and Cleaning

- Allow all parts to **cool completely** before handling.
- Wash the Kettle, Infuser Basket, Kettle Lid, and Infuser Lid in warm soapy water using a soft sponge or nylon pad.
- Rinse thoroughly and dry all parts completely.
- **Empty all remaining water** after each use and wipe dry.

⚠️ Leaving water in the Kettle for extended periods may cause corrosion or discoloration and could void the warranty.




Figure 2

Warnings

Do not heat the Kettle when empty.

Never allow the Kettle to boil dry. If it does, allow it to cool completely before handling.

Never leave the Kettle unattended while on a hot burner.

Always empty excess water after use.

Allow all parts (Kettle, Infuser Basket, Infuser Lid, and Kettle Lid) to cool completely before cleaning.

Notes

[illegible]

Notes

[illegible]